

SM-100 DIRECT FIRE MELTER

Operating Instructions & Parts Manual



SealMaster®

Pavement Products & Equipment

PO Box 2277 • Sandusky, Ohio 44870 • 419-626-4375

SealMaster

ThorWorks Industries, Inc.

Item Purchased: _____ Model No.: _____
Serial No.: _____ Acceptance/Ship Date: _____
Company: _____ Contact: _____
Address: _____ City: _____
Zip/Postal Code: _____ State: _____ Country: _____

CORRESPONDENCE

All correspondence regarding this equipment or general correspondence should be addressed to:

ThorWorks Industries, Inc.
PO Box 2277
Sandusky, OH 44870

In referring to the equipment, kindly state the Model Number, Serial Number and any Part Number involved.

THORWORKS
INDUSTRIES

Table Of Contents

Warranty	1
Operating Instructions	2-3
Parts List	4-5
LP Gas Schematic	6
Assembly Schematics	7-9
Hydraulic Oil Specifications	10-11
Hydraulic Oil MSDS	12-18
Heat Transfer Oil Specifications	19
Heat Transfer Oil MSDS	20-26

SealMaster Limited Warranty

SealMaster warrants that its products are of quality material and workmanship. SealMaster agrees to replace, within a period of one (1) year from date of delivery, or at its option, repair, without charge, any part of their manufacture which proved defective. The repair or replacement will be free of charge F.O.B Sandusky, Ohio, proving the damaged part or parts are returned, freight prepaid, to SealMaster and investigation show such repair or replacement is made necessary by inherent defect of material or workmanship.

It is hereby understood that engines, motors, pumps, or other components purchased by SealMaster for use on its equipment are not warranted by SealMaster and are sold only with the standard warranty of the manufacturer of that component.

SealMaster will make no allowances for repairs or alterations completed by outside sources unless authorization is in writing and approved by an authorized SealMaster representative.

Any claims for defective material or workmanship must be made prior to the expiration of thirty (30) days from the date failure occurs, and in all cases prior to the expiration of the warranty period of one (1) year. It is the intent of this paragraph to limit SealMaster's liability solely to the cost of replacement parts, F.O.B. factory, or at the option of SealMaster to repair of the defective part or parts. No allowances for damages, lost time, or any other claim will be recognized.

This warranty is null and void if other than genuine SealMaster parts are used.

SealMaster is constantly striving to improve their products. Changes in design and improvement will be made whenever the manufacturer believes the efficiency of the product will be improved, without incurring any obligation to incorporate such improvements in any machines which have been shipped or are in service.

In an effort to continue to improve product quality, SealMaster reserves the right to change specifications without notice.

Any modification or alteration of this machine without prior approval of the manufacturer may void this warranty.

CRACK PRO 60 & 100

OPERATING INSTRUCTIONS

1. Check engine oil level-follow manufacturers guidelines as to type and frequency of changes.
2. Check hydraulic oil level-use grade AW68 hydraulic oil.
3. Check heat transfer oil level with dipstick #25,-use UNOCAL UNAX RX68 only.
NEVER CHECK WHEN HOT!
4. Fill fuel tank with fresh gasoline.**NEVER FILL FUEL TANK WITH A LIT BURNER!**
5. Make sure the agitator control valve is in the neutral position.
6. Open the temperature control box #7, and turn the temperature control knob all the way clockwise to its lowest setting #8. This will prevent the burners from lighting prematurely. Remove burner access door # 31.
7. Open the LP gas tank valve.
8. Turn the pilot knob on the gas valve #9 to the pilot position. Light the hand torch #5 and place it in the burner opening .Position it by the pilot light assembly #14, depress the pilot knob and remove the hand torch when you see that the pilot flame is lit. Hold the pilot knob in for at least 30 seconds. Release the knob and turn it to the on position.
9. Turn the thermostat control to its 500° setting, the burners will now light.
10. Replace the burner access door..
11. Open the material tank lid and place inside three boxes of material. Close the lid.
12. When the material thermometer #16, reaches 300° start the engine and engage the agitator control valve #23 to the forward position. If the agitator will not turn, return the valve to the neutral position, and try again in a few minutes.
13. When there is a few inches of liquid material in the tank you can add more blocks if desired. **CAUTION: ALWAYS STOP THE AGITATOR WHEN OPENING THE LID FOR ANY REASON.**
14. As the material temperature gets close to the recommended pouring temperature, you need to turn the temperature control down so that the material temperature and the oil #15, are close together. When constantly adding blocks of material the temperature control should be set about 50° higher than the material pouring temperature.

15. If the material temperature starts to climb over the recommended pouring temperature open the lid and add more blocks. Leaving the lid open will also help drop the temperature.

16. Set pour pot or applicator under the pour off valve #30 and raise the handle to open. **CAUTION: ALWAYS WEAR LONG SLEEVE SHIRT, GLOVES AND A FACE SHIELD WHEN PERFORMING THIS OPERATION !**

17. Fill pour pot to desired level and pour into cracks. Follow with a V-shaped squeegee if desired.

18. To stop for the day perform the following steps:

1. Turn the temperature control knob to its lowest setting, at least a 1/2 hour before completing work..
2. Put agitator control valve in neutral.
3. Shut off engine.
4. Turn off propane tank.

NOTE: Oil temperature must be allowed to cool down to the maximum pouring temperature of the material prior to stopping agitation. If the machine is turned off without allowing cool down time the material could be burned.

CRACK PRO

REF #	ITEM	PARTS LIST	
		PART #	QTY
1	TANK CONNECTOR	P933A001	1
2	1/2" L.P.GAS HOSE	P669B007	1
3	HAND TORCH REGULATOR	P735A015	1
4	1/4" L.P.GAS HOSE	P669A005	1
5	HAND TORCH	P75000B010	1
6	MAIN BURNER REGULATOR	P735A034	1
7	TEMPERATURE CONTROL BOX	P941A010	1
8	TEMPERATURE CONTROL	P735A035	1
9	GAS VALVE	P735A036	1
10	1/2" L.P.GAS HOSE	P669B006	2
11	NEEDLE VALVE -OLDER MACHINES	P666A001	2
12	GAS BURNER	P662B030	2
13	THERMOPILE SENSOR	P679A006	1
14	PILOT LIGHT ASSY	P735A037	1
15	OIL THERMOMETER	P659A004	1
16	MATERIAL THERMOMETER	P659A009	1
	100 GALLON THERMOMETER	P659A008	1
17	OIL EXPANSION TANK	P75000B005	1
18	TEMPERATURE PROBE (PART OF TEMP.CONTROL)	N/A	1
19	HYDRAULIC OIL TANK / PUMP	P601A025	1
20	JAW COUPLER	P630A035	2

CRACK PRO


PARTS LIST


REF #	ITEM	PART #	QTY
20	JAW COUPLER	P630A032	1
20	COUPLER INSERT	P031A005	1
21	5.5 HP HONDA	P458A027	1
22	FENDER	P649A001	2
23	AGITATOR CONTROL VALVE	P472A004	1
24	OIL OVERFLO PIPE	P750008006	1
25	OIL DIPSTICK	P750008001	1
26	AGITATOR DRIVE MOTOR	P474A042	1
27	EXHAUST FLUE	N/A	3
28	OUTER TANK WRAP	N/A	1
29	LOWER AGITATOR BUSHING	P439A004	1
30	MATERIAL POUR OFF VALVE	P585B000	1
31	BURNER ACCESS DOOR	N/A	1
32	TAIL LIGHT	P516A001	2
33	TIRE AND WHEEL ASS'Y	P514A015	2
34	TORSION AXLE AXLE FOR 100 GALLON	P511A011 P511A012	1 1
35	PROPANE TANK LATCH	N/A	1
36	PINTLE EYE COUPLER	P646A003	1
37	2 5/16" BALL COUPLER	P553A008	1
38	1 7/8" & 2" BALL COUPLER	P550A000	1
39	MATERIAL TANK LID	N/A	1
40	1/2" HYD HOSE ASS'Y	N/A	1
41	1/2" HYD HOSE ASSY	N/A	1
42	5/8" HYD HOSE	N/A	1

CRACK PRO


PARTS LIST			
REF #	ITEM	PART #	QTY
43	TRAILER JACK	P551A005	1
44	SAFETY CHAIN	P531A030	2
45	CHAIN HOOK	P517A001	2
46	SPLINE COUPLER	P630A043	1
47	AGITATOR SHAFT	P750008012	1
	AGITATOR SHAFT / 100 GALLON	P740008008	1
48	BLADE SUPPORT	N/A	2
49	BLADE	P750008011	2
50	L.P. TANK HOLDER	N/A	1
51	L.P.TANK / NOT INCLUDED	N/A	1

L.P. GAS SCHEMATIC







FRONT SIDE VIEW



FRONT VIEW





Agitator Assembly



LUBRICANTS

Product Information

CITGO A/W HYDRAULIC OILS

DESCRIPTION: CITGO A/W Hydraulic Oils are superior antiwear hydraulic and circulating fluids - specially formulated with high quality base stocks and improved thermally stable additives. These oils offer outstanding resistance to sludge formation, are chemically stable, and exhibit excellent antiwear protection.

QUALITIES: CITGO A/W Hydraulic Oils are made from top quality base stocks and contain all the necessary additive components to offer trouble-free service in high-pressure, high-output industrial hydraulic circuits. CITGO A/W Hydraulic Oils have these outstanding properties:

CITGO A/W Hydraulic Oils utilize the latest in thermally stable zinc-type additives. This virtually eliminates the formation of heat-related sludging in sensitive electro-hydraulic servos associated with conventional zinc-type oils. These oils are wholly suitable for NC machine tools and other high-output equipment where sustained heat is prevalent.

These oils exhibit superior hydrolytic stability in the presence of water and will not contribute to either the formation of metal-etching acids or corrosive reactants.

CITGO A/W Hydraulic Oils are inhibited against rusting in both fresh and sea water and pass both A and B Sequences of the ASTM D 665 Turbine Oil Rust Test.

These oils offer the optimum in antiwear protection to pumps, motors, valves, and other hydraulic circuit components. They are approved against stringent performance requirements including Cincinnati Milacron P-58, P-59 and P-70, Denison HF-O, and Vickers M-2950-S and I-286-S.

CITGO A/W Hydraulic Oils resist foaming and will not foster abnormal air entrainment in properly designed hydraulic circuits. The oils also readily and rapidly separate water permitting sump drain-off of the contaminating water.

APPLICATIONS: CITGO A/W Hydraulic Oils are recommended for service in vane, piston, and gear pumps when used in accordance with the manufacturers' recommendations. The oils are designed to provide maximum service life to these pumps as well as to other circuit components such as motors and servos.

CITGO A/W Hydraulic Oils are also recommended for use as gear and bearing lubricant in industrial applications where rust and oxidation inhibited oils are required.

(over)



CITGO A/W All-Temp Hydraulic Oil is a special multigrade antwear oil for use in mobile equipment where wide temperature ranges are encountered. Its features include pour point depression to -40°F, high viscosity index, resistance to oxidation, foaming and corrosion as well as protection against pump component wear. CITGO A/W All-Temp Hydraulic Oil is highly recommended for use in mobile and other hydraulic equipment in heavy-duty all-weather service. Meets FMC Hi-Performance, Hydraulic Oil, Grade 32 requirements.

CITGO A/W Hydraulic Oils meet the general physical and performance requirements of the European classifications as follows:

DIN 51524 Part 2 (HLP) ISO-VG Grades MV and 22-100.

TYPICAL PROPERTIES:

CITGO A/W HYDRAULIC OILS

GRADE	All Temp ⁽¹⁾	22	32	46	60	100	150
Commodity Code	33602	33410	33415	33420	33430	33440	33450
Gravity	32.1	31.9	31.3	30.4	29.6	29.0	28.2
Pounds Per Gallon	7.20	7.21	7.24	7.28	7.31	7.34	7.40
Flash Point, °F (°C), COC	439 (226)	433 (222)	414 (212)	408 (242)	464 (240)	475 (246)	471 (244)
Viscosity, cP @ 0°C ⁽²⁾	1170	—	—	—	—	—	—
cSt @ 40°C	30	21.5	22	46	68	98	150
cSt @ 100°C	6.1	4.2	5.5	6.8	8.5	10.9	14
SUS @ 100°F	155	113	171	207	252	514	781
SUS @ 210°F	46	40.5	45	49	55	63	77
Viscosity Index	154	97	100	102	94	94	94
Pour Point, °F (°C)	-40 (-40)	-45 (-43)	-33 (-34)	-27 (-32)	-20 (-29)	+5 (-15)	+5 (-15)
Color, ASTM D 1500	L1.5	L1.0	L1.0	L1.0	L1.5	L3.0	L4.0
Emulsion Test, ASTM D 1401 ⁽³⁾	38-39-3	—	38-39-3	39-40-1	40-40-0	40-40-0	40-40-0
Hydraulic Pump Test, ASTM D 2862 ⁽⁴⁾ 2000 PSI, 100 Hrs., 175°F Mg Ring + Vane Loss	25	—	25	25	28	28	28
Oxidation Test, ASTM D 943, Hrs.	2800	2400	2400	2400	2300	1600	1550
Rust Test, ASTM D 655 A, B ⁽⁵⁾	Pass	Pass	Pass	Pass	Pass	Pass	Pass
Meets Vickers Requirements M-2850-S ⁽⁶⁾	Yes	Yes	Yes	Yes	Yes	—	—
Meets Vickers Requirements I-285-S ⁽⁷⁾	Yes	Yes	Yes	Yes	Yes	—	—
Meets Denison HF-O Requirement	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Meets Cincinnati Milacron Requirement	—	—	P-63	P-70	P-69	—	—
ASTM Grade	150	105	150	215	315	465	700
DIN 51524 Part 2 Grade	HLP (MV)	HLP 22	HLP 32	HLP 46	HLP 68	HLP 100	NA
ISO VG No.	32 ⁽⁸⁾	22	32	46	68	100	150

Notes: (1) Meets FMC Hi-Performance, Hydraulic Oil, Grade 32 requirements.

(2) ASTM D 2893 Brookfield Viscosity.

(3) 30 minutes max. separation time.

(4) Test utilizes Vickers 104c or 105c vane pump.

(5) Pass - No Rust.

(6) This requirement utilizes Vickers 35VO25A vane pump test. It is for mobile equipment.

(7) This requirement utilizes Vickers 104c or 105c vane pump test, ASTM D 2862, and is for industrial, stationary systems.

(8) A multigrade, high VI type which may be used in most applications requiring a multiviscosity range of ISO-VG 22, 32, 46.



CITGO Petroleum Corporation
P.O. Box 3758
Tulsa, Oklahoma 74102

Material Safety Data Sheet

Trade Name: CITGO A/W Hydraulic Oil 68
Commodity Code: 33-430
Synonyms: Lubricating Oil Date: March 15, 1993
CAS No.: Mixture Technical Contact: (918) 495-5933
(Refer to Section 1) Medical Emergency: (918) 495-4700
Citgo Index No.: 0227 Chemical Emergency: (800) 424-9300

Material Hazard Evaluation

(Per OSHA Hazard Communication
Standard [29 CFR Part 1910.1200]) (OHCS)

Health: Final Product Non-Hazardous.

Precautionary Statement: Do not inhale mists or fumes.

HMIS Rating¹: Health 0 Flammability 1 Reactivity 0

1.0 Generic Composition / Components

Components	CAS #	%	Hazard Data
Refined Petroleum Oil(s)	64742-65-0 64741-88-4	> 99	Oral LD50(rat): > 5g/kg
Anti-wear rust and oxidation inhibitor additives (contains Zinc Dialkyldithiophosphate)	Mixture	< 1	LD50(rat): ~ 2g/kg Skin and eye irritant
Anti-foam Agent	Mixture	< 0.1	Skin, eye and respiratory irritant Ingestion: Hazardous-may be aspirated into the lungs

¹ Hazard Rating: least-0; slight-1; moderate-2; high-3; extreme-4
Citgo assignment based on our evaluation per NPPA and NPRA guidelines.

NA - Not Applicable

ND - No Data

NE - Not Established

2.0 Physical Data

Physical Hazard Classification (Per 29 CFR Part 1910.1200)

No	Combustible	No	Flammable	No	Pyrophoric
No	Compressed Gas	No	Organic Peroxide	No	Reactivity
No	Explosive	No	Oxidizer	Yes	Stable

Boiling Point, 760 mmHg, °C(F): ~416(~750)
Specific Gravity (60/60°F) (H₂O = 1): 0.89
Vapor Density (Air = 1): > 1
% Volatiles by Volume: Negligible
Melting Point, °C(F): NA
Vapor Pressure, mmHg (25°C): ND
Solubility in H₂O, % by Weight: Negligible
Evaporation Rate (Butyl Acetate = 1): < 1
pH of Undiluted Product: NA
Appearance and Odor: Amber liquid, slight sulfurized odor.

3.0 Fire and Explosion Data

Flash Point, COC, °C(F)	240(465)
Flash Point, PMC, °C(F)	221(429)
Fire Point, COC, °C(F)	265(510)
NFPA Rating ²	Health: 0 Flammability: 1 Reactivity: 0
Flammable Limits (% by volume in air)	Lower: NA Upper: NA
Extinguishing Media	CO ₂ , dry chemical, foam, water fog
Special Fire Fighting Procedure	None.
Unusual Fire or Explosion Hazard	Water may cause frothing.

4.0 Reactivity Data

Stability: Stable

Conditions Contributing to Instability: None.

Incompatibility: Strong oxidants.

Hazardous Decomposition Products:
(thermal, unless otherwise specified)
CO₂ (CO under incomplete combustion)
Traces of oxides of S, P, Zn, Ca and Mg.

Conditions Contributing to Hazardous Polymerization:

None.

² Hazard Rating: least-0; slight-1; moderate-2; high-3; extreme-4
Cargo assignment based on our evaluation per NFPA guidelines.

5.0 Spill or Leak Procedures

Procedure if Material is Spilled:

- Remove sources of heat or ignition, provide adequate ventilation, contain leak.
- *Small Spills:* Absorb with suitable material such as rags, straw or sand. Place into containers for later removal.
- *Large Spills:* Contain spill in earthen dikes for later recovery.
- Report spills as required to appropriate authorities.

Waste Disposal:

- It is the responsibility of the user to determine if the material is a hazardous waste at the time of disposal.
- Check before disposing to be sure you are in compliance with all applicable laws and regulations.
- RCRA Emergency Hotline Number: 800-424-9346.

Protective Measures During Repair and Maintenance of Contaminated Equipment:

- Refer to Section 7.0 - Special Protection Information.
- Avoid prolonged contact with used oil.
- Wash exposed skin thoroughly with soap and water.
- Remove soiled clothing.
- Use oil impervious gloves if direct contact is expected.

6.0 Health Hazard Data

Health Hazard Classification

(Per 29 CFR Part 1910.1200)

No	Carcinogen	No	Corrosive
No	Animal Carcinogen	No	Irritant
No	Suspect Carcinogen	No	Sensitizer
No	Mutagen	No	Teratogen
No	Highly Toxic	No	Target Organ
No	Toxic	—	—

Product listed as Carcinogen or Potential Carcinogen by:

NTP No IARC No OSHA No Other No

Toxicity Summary: General toxicity low.

Major Route(s) of Entry: Inhalation of incidental mists or vapors.

Acute Exposure Symptoms

<i>Inhalation:</i>	Low risk of inhalation at ambient temperatures. Mists or fumes may cause drowsiness, dizziness, headache, nausea, or lung irritation or chemical pneumonitis.
<i>Dermal Contact:</i>	Transient, slight irritant
<i>Eye Contact:</i>	May be mildly irritating.
<i>Ingestion:</i>	Low toxicity. At a Saybolt viscosity of 350 SUS (100°F), there is still a slight risk of aspiration into the lungs. If a few drops are ingested, material may pass through the system without harm. On ingestion of large quantities, slight GI discomfort, diarrhea, and headache may occur. Lethal dose is about 1 part for a 150 lb. human adult.
<i>Injection:</i>	Subcutaneous or intramuscular injection may cause irritation, erythema, edema.

Chronic Exposure

Prolonged and/or frequent contact may cause drying, cracking (dermatitis) or folliculitis.

Other Special Effects

None expected.

Medical Conditions Aggravated by Exposure

None.

First Aid and Emergency Procedures for Acute Effect

<i>Inhalation:</i>	Remove to fresh air. Respiratory support, if necessary. Seek medical aid.
<i>Dermal:</i>	Wash with soap and water. Do not wear heavily contaminated clothing before laundering.
<i>Eye:</i>	Flush with large volumes of water. Seek physician if any complications arise.
<i>Ingestion:</i>	Induce vomiting. Seek medical aid.
<i>Injection:</i>	Subcutaneous injection is a medical emergency. Seek medical aid immediately.

Notes to Physician: Following ingestion at a viscosity of about 350 SUS (100°F), there may be a slight risk of aspiration into the lungs. Emesis may be considered. Subcutaneous or intramuscular injection requires prompt surgical debridement. If not familiar with technique, seek skilled advice.

7.0 Special Protection Information

Ventilation Requirements: Use in well ventilated area. In confined space, mechanical ventilation may be required to keep levels of certain components below mandated standards as evaluated by designated personnel.

Permitted Threshold Air Concentrations:

Mineral Oil Mist	TLV-TWA	5 mg/m ³	OSHA-PEL	5 mg/m ³
	TLV-STEL	10 mg/m ³	OSHA-STEL	ND
	TLV-Ceiling	ND	OSHA-Ceiling	ND

Specific Personal Protective Equipment:

Respiratory: Normally none required. If high vapor or mist concentrations expected, use respirator approved for organic vapors and mists.

Eyes: Safety goggles, or chemical splash goggles if splashing is anticipated.

Dermal: Oil impervious gloves if frequent or prolonged contact is expected.

Other Clothing or Equipment: Wear body-covering work clothes to avoid prolonged or repeated exposure. Launder soiled work clothes before reuse.

8.0 Transportation and Special Precautions

Storage: Do not apply high heat or flame to container. Keep separate from strong oxidizing agents.

Caution: Empty containers may contain product residue which could include flammable or explosive vapors.

Consult appropriate Federal, State and Local authorities before reusing, reconditioning, reclaiming, recycling or disposing of empty containers and/or waste residues of this product.

DOT Information

Proper Shipping Name:	Petroleum Lubricating Oil.
Hazard Class:	Non-Hazardous.
Hazard Identification Number:	None assigned.
Placard:	None.
Compatibility Category:	Group 33.
CHRIS Code:	OMN

9.0 Environmental Data

Product Name: CITGO A/W Hydraulic Oil 68
Commodity Code: 33-430

SARA TITLE III

Section 313 - Toxic Chemicals

This product does not contain toxic chemicals of Section 313 of Title III of Superfund Amendments and Re-authorization Act of 1986 (SARA) and 40 CFR Part 372.

<u>Components</u>	<u>CAS#</u>	<u>%</u>
.	.	.

Section 311 - Hazard Categories

<u>Yes</u>	<u>Not Applicable</u>	<u>No</u>	<u>Fire Hazard</u>
<u>No</u>	<u>Acute (Immediate Health Hazard)</u>	<u>No</u>	<u>Sudden Release of Pressure Hazard</u>
<u>No</u>	<u>Chronic (Delayed Health Hazard)</u>	<u>No</u>	<u>Reactive Hazard</u>

Section 302/(A) - Extremely Hazardous Substances

(RQ = Reportable Quantity)
(TPQ = Threshold Planning Quantity)

This product does not contain Extremely Hazardous Substances of Section 302/(A).

<u>Component</u>	<u>CAS#</u>	<u>%</u>	<u>RQ lbs.</u>	<u>TPQ lbs.</u>
<u>None</u>

Clean Water Act

Under Section 311 (b) (4) of the Clean Water Act, discharges of crude oil and petroleum products in any kind or form to surface waters must be immediately reported to the National Response Center: 800-424-8802.

Comprehensive Environmental Response, Compensation & Liability Act (CERCLA) - Section 102 Hazardous Substances

<u>Component</u>	<u>CAS#</u>	<u>%</u>	<u>RQ lbs.</u>
.	.	.	.

Petroleum and petroleum fractions are excluded from the list of CERCLA hazardous substances by Section 101(14) of CERCLA.

New Jersey Worker and Community Right-to-Know Act

Petroleum Oil

Federal Regulations

Reported in TSCA Inventory:

<u>Product Components</u>	<u>Yes</u>	<u>No</u>	<u>x</u>	<u>NA</u>
<u>None</u>	<u>Yes</u>	<u>No</u>	<u>x</u>	<u>NA</u>

NA - Not Applicable

ND - No Data

NE - Not Established

10.0 Labeling

NOTE

This product has been determined not to be a physical or a health hazard as defined by the OSHA Hazard Communication Standard.

ALL STATEMENTS, INFORMATION, AND DATA PROVIDED IN THIS MATERIAL SAFETY DATA SHEET ARE BELIEVED TO BE ACCURATE AND RELIABLE, BUT ARE PRESENTED WITHOUT GUARANTEE, REPRESENTATION, WARRANTY, OR RESPONSIBILITY OF ANY KIND, EXPRESSED OR IMPLIED. ANY AND ALL REPRESENTATIONS AND/OR WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE SPECIFICALLY DISCLAIMED. USERS SHOULD MAKE THEIR OWN INVESTIGATIONS TO DETERMINE THE SUITABILITY OF THE INFORMATION OR PRODUCTS FOR THEIR PARTICULAR PURPOSE. NOTHING CONTAINED HEREIN IS INTENDED AS PERMISSION, INDUCEMENT, OR RECOMMENDATION TO VIOLATE ANY LAWS OR TO PRACTICE ANY INVENTION COVERED BY EXISTING PATENTS, COPYRIGHTS OR INVENTIONS.

NA - Not Applicable

ND - No Data

NE - Not Established

DIESEL



BURNER

SUPPLEMENT


Crack Pro

ThorWorks Industries, Inc.
Sandusky, Ohio
(419) 626-4375

TEMPERATURE CONTROL



The top scale is the current temperature of the heat transfer oil. The bottom scale is the temperature that you want the oil to be heated to. The burner shuts off when your setting is exceeded by 10 degrees. It comes back on when the oil drops to 10 degrees under your setting. The sequence for setting the temperature is: Press the left arrow 3 times, then press up or down to get the 4, press the left arrow again, then up or down for the 7, press the left arrow again, then up or down for the 5, then press SET.



TERMINALS

P - Battery Positive loop wire

B - Red wire in Burner

N - Battery Negative loop wire

G - Black wire in Burner, Ground wire

C - Red with white trace in Oil Burner

D - White in Oil Burner

Crack Pro

ThorWorks Industries, Inc.
Sandusky, Ohio
(419) 626-4375

BURNER REPLACEMENT PARTS

REF.#	ITEM	PART #	QTY
1	Motor	P662A012	1
2	Blower wheel	P662A013	1
3	Coupling	P002A016	1
4	Air guide	P662A022	1
9	Pump	P662A011	1
10	Tube assembly	P662A019	1
11	Oil valve	P662A020	1
14	Electrode kit	P662A018	1
15	Cad cell	P662A014	1
17	Igniter	P662A015	1
21	Igniter control board (primary)	P662A010	1
NS	Nozzle (specify size)	P662A017	1
	Complete burner	P662A009	1

MODEL **ADC** Oil
Burner

Instruction Manual

Type "F" air tube combinations



Thank you for purchasing a
Beckett burner. With proper care
and regular maintenance, it will
provide years of trouble-free
service. Please take a few minutes
to read the section entitled 'To the
Owner' inside this manual. Then,
keep the manual in a safe place
where it can be easily located if
needed by your professional
service technician.

Beckett

Contents

1. Prepare before installing	
A. Verify specifications	3
B. Be aware of hazard definitions	3
C. Notice special requirements	3
2. General information	
A. Equipment located in confined space	4
B. Exhaust fans and other air-using devices	4
C. Clearances to burner and equipment	4
D. Exhausting hazardous fumes	4
E. Low firing rate baffle	4
3. Nozzle, Line, Electrode, & Igniter Maintenance	
A. Nozzle Assembly Maintenance	5
B. Replace Burner Nozzle	5
C. Check & Adjust Electrodes	6
D. Igniter Maintenance	6
E. Nozzle Line Assembly Maintenance	6
F. Check & Adjust 'Z' Dimension	6
4. Fuel Supply Maintenance	
A. Connect Fuel Lines	7
B. Fuel Supply Level or Above Burner	7
C. Fuel Supply Below Level of Burner	7
D. Fuel Line Replacement	7
E. Fuel Line Valve and Filter	7
5. Burner Maintenance and Wiring	
A. Burner Installed on washer	7
B. Replacement Burner Installation	7
6. Drive Component Maintenance	
A. Motor, Blower Wheel, and Coupling Replacement	9
B. Pump Maintenance and Replacement	10
C. Valve Replacement	10
7. Start up Burner and Set Combustion	
A. Basic burner operation	11
B. Combustion set up	11
C. Set combustion with test instruments	11
Appendix A. Maintain & Service burner	
A. Owner's Information	12
B. Owner Service & Maintenance	12
C. Daily Maintenance	12
D. Weekly Maintenance	12
E. Regular Service/Maintenance	12
Appendix B. Burner Troubleshooting	
Troubleshooting Chart	13
Appendix C. Replacement Parts	
Burner Exploded View	15

1. Prepare before installing

A. Verify specifications

Capacity	'T' heads	
	Firing rate	0.75 - 2.50 GPH
	Input	105,000 - 350,000 Btu/h
Fuels	U. S. No. 1 or No. 2 diesel fuel, or kerosene - No.1 or No. 2 heating oil (ASTM D396)	
Electrical	Power supply	13.5 VDC
	Operating load	15 Amps w/ igniter on, 6-10 Amps w/ igniter turned off
	Motor	13.5 VDC, 1/6 hp, 3450 rpm.
		10 Amps (max.), NEMA "M" flange, rotation CCW when facing shaft end
	Ignition Secondary	20KVpk 30mA . Interrupted duty OR optional continuous duty
Pump	Outlet pressure	Note 1
Air tube	ATC code	See Table 1
Dimensions	Height (maximum)	11 1/8 inches
	Width (maximum)	14 7/8 inches
	Depth (chassis only)	5 3/16 inches
	Air tube diameter	4 inches
Temperature	100° Max air temperature	
Note 1. See equipment manufacturer's burner specifications for recommended outlet pressure. Pressure is 100 psig unless otherwise noted.		

Table 1- Air Tube Combination (ATC) codes*

Firing rate (gph) (min-max)	Head	Static plate size (inches)	ATC codes for usable air tube lengths: ("A" in inches; see Figure 2)			
			4 1/8	5	5 1/8	6 1/8
0.40-0.75	F0	3 1/8 U	AF44XR	-	AF53XR	AF65XR
0.75-1.25	F3	2 1/8	AF44XN	-	AF53XN	AF65XN
0.85-1.35	F4	2 1/8	AF44WH	-	AF53WH	AF65WH
0.85-1.65	F6	2 1/8	AF44YB	-	AF53YB	AF65YB
1.10-2.00	F12	2 1/8	AF44XD	-	AF53XD	AF65XD
1.60-2.50	F22	2 1/8	AF44XP	-	AF53XP	AF65XP

B. Be aware of hazard definitions

DANGER

Denotes presence of a hazard which, if ignored, will result in severe personal injury, death, or substantial property damage.

WARNING

Denotes presence of a hazard which, if ignored, could result in severe personal injury, death, or substantial property damage.

CAUTION

Denotes presence of a hazard which, if ignored, could result in minor personal injury or property damage.

NOTICE

Intended to bring special attention to information, but not related to personal injury or property damage.

C. Notice special requirements

DANGER

- This equipment must be installed, adjusted and started only by a qualified service agency – an individual or agency, licensed and experienced with all codes and ordinances, who is responsible for the installation and adjustment of the equipment. All oil burners should be installed in accordance with regulations of the latest revision of the National Fire Protection Association Standard NFPA 31 and in complete accordance with all local codes and authorities having jurisdiction. Regulation of these authorities take precedence over the general instructions provided in this installation manual. Note that this burner is NOT recommended for Residential use.

- For recommended installation practice in Canada, refer to the latest version of CSA Standard B139.

WARNING

Read all instructions before proceeding. Follow all instructions completely. Failure to follow these instructions could result in equipment malfunction, causing severe personal injury, death or substantial property damage.

NOTICE


Concealed damage — If you discover damage to the burner or controls during unpacking, notify the carrier at once and file the appropriate claim.

NOTICE

When contacting Beckett for service information — Please record the burner serial number (and have available when calling or writing). You will find the serial number on the silver label located on the left rear of the burner. See illustration below.

Instruction Manual – Model ADC Oil Burner

Figure 1 – Typical Burner Nameplates



2. General Information

Your burner was designed, installed and adjusted at the factory prior to shipment and should not require additional adjustments. Refer to the Troubleshooting section of this manual when experiencing a possible fault condition.

BANGER

The Model ADC Burner requires a continuous supply of 11 to 16 volts DC at 15 amperes measured at the burner during operation. An automotive or a small engine charging system that is capable of supplying the required continuous voltage/ampereage is recommended with certain road equipment, such as asphalt hot patchers and similar applications. This is especially true while maintaining nominal load temperatures during idle periods. A low or erratic power supply could result in impaired burner operation, severe delayed ignition or an explosion inside the heat exchanger resulting in a burn and/or asphyxiation hazard.

ANSWER

If the burner is not supplied with a reliable combustion air source, the burner cannot properly burn the fuel. This would result in incomplete combustion, causing sooting and probable emission of carbon monoxide. Severe personal injury, death or substantial property damage could occur.

Burner head type	Low Firing Rate Baffle, if specified:
F0	up to 0.65 gph
F3	up to 0.65 gpm
F4 or F6	up to 0.90 gpm

A. Equipment located in confined space

The confined space should have two (2) permanent openings: one near the top of the enclosure and one near the bottom of the enclosure. Each opening shall have a free area of not less than (1) one square inch per 1,000 BTU's per hour of the total input rating of all equipment within the enclosure. The openings shall have free access to the building interior, which should have adequate infiltration from the outside.

B. Exhaust fans and other air-using devices

(Typically not used)

Size air openings large enough to allow for all air-using devices in addition to the minimum area required for combustion air. If there is any possibility of the equipment room developing negative pressure (because of exhaust fans, for example), either pipe combustion air directly to the burner or provide a sealed enclosure for the burner and supply it with its own combustion air supply.

C. Clearances to burner and equipment

- Provide space around burner and equipment for easy service and maintenance.
 - Check minimum clearances against those shown by the equipment manufacturer and by applicable codes.

D. Exhaustion Hazardous Events

An asphyxiation hazard could exist due to improper combustion levels that impair proper burner operation. Copious amounts of smoke and carbon monoxide could be produced in a confined area. Also, be conscious of any fumes produced by the materials that are being heated. Always ensure adequate ventilation to exhaust all fumes.

E. Low Flying Rate BarTts


The Low Firing Rate Baffle (LFRB) (see Replacement Parts) reduces the air flow and pressure. The LFRB is sometimes used for firing rates under 1.00 GPH as listed in the table below. Refer to the equipment manufacturer's instructions. Do not omit the LFRB when specified. Omitting the baffle when specified or installing the baffle when not specified could result in poor burner performance.

3. Nozzle, Nozzle Line, & Electrode Maintenance

A. Nozzle Maintenance

Refer to the following figure for nozzle, nozzle line and electrode familiarization.

Figure 2 – Nozzle, line & electrode assembly



Item #	Description
1	Electrode Contact (3° ATC or Extension over 3°)
2	Nozzle Line
3	Spider Spacer Assembly
4	Static Plate
5	Electrode Clamp
6	Electrode Clamp Retaining Screws
7	Nozzle Line Set Screw
8	Electrode Insulator
9	Nozzle Adapter
10	Nozzle Tip
11	Electrode Tip


B. Replace burner nozzle

WARNING

Make certain the correct nozzle is selected for the actual pump pressure. Nozzles are rated for 100 psig operation. For applications with pump pressure above 100 psig, the nozzle rated capacity will be lower than the equipment firing rate. Use only the specified spray pattern. Failure to use the correct nozzle size and type can result in unacceptable combustion, possibly causing severe personal injury, death or substantial property damage.

1. If applicable, remove the plastic plug protecting the nozzle adapter threads.
2. Place a $\frac{1}{2}$ " open-end wrench on the nozzle adapter. Insert the nozzle into the adapter and finger tighten. Finish tightening with a $\frac{1}{2}$ " open-end wrench.
3. If the nozzle is already installed, remove the nozzle line assembly to verify that the nozzle size and spray pattern are correct for the application (per equipment manufacturer's information). Verify that the electrode tip settings comply with Figure 3.

Figure 3 – Electrode Tip Settings



CAUTION

Use care when removing and installing oil nozzles:

- Inspect the nozzle adapter prior to installing the nozzle. If the sealing surface is grooved or scratched, replace the nozzle line assembly. If a damaged nozzle adapter is not replaced, oil could leak at the nozzle-adapter joint, causing serious combustion problems.
- Protect the nozzle orifice and strainer when installing a nozzle. If there is dirt in the orifice or it is scratched or damaged, the nozzle will not function properly.
- Do not over-torque the nozzle when installing. This will cause deep grooves in the nozzle adapter, preventing a seal when a new nozzle is installed.
- Use a wrench that secures the adapter or use 3/4" and 5/8" open-end wrenches. DO NOT attempt to remove or install a nozzle without securing the adapter. The nozzle alignment could be seriously damaged.
- Do not squeeze the electrodes too tightly when handling the nozzle line assembly. This could change the electrode tip settings or damage the ceramic electrode insulators.

Instruction Manual – Model ADC Oil Burner

- Carefully check and realign electrode tips after replacing the nozzle, ensuring the electrode settings comply with Figure 3.

C. Check/adjust electrodes

Check the electrode tip settings. Adjust if necessary to comply with the dimensions shown in Figure 3. To adjust, loosen the electrode clamp screw and slide/rotate electrodes as necessary. Securely tighten the clamp screw when finished.

D. Igniter Maintenance


The igniter assembly does not require any adjustments beyond making sure the springs and the burner electrode rods make solid contact when the igniter is in the closed position. The sealing surfaces of the gaskets should be checked and replaced at the first signs of any damage or deterioration. Clean any dirt or residue from the porcelain bushings, springs, and baseplate.

The simplest way to check igniter operation is by supplying voltage to the input and checking to see whether an arc is produced. Check by either looking or listening to see if there is an arc across the electrodes while the burner is running and the igniter is energized.

The igniter must be grounded to the burner before checking the following. To check the igniter, insure that the burner is off, and use an ohmmeter to check the resistance between one of the springs and exposed metal on the burner (for example, a housing bolt). The meter should read less than 2000 ohms when measuring the spring-to-ground resistance at either spring.

The igniter should be replaced if the meter indicates an open circuit, the difference between the two spring-to-ground resistance readings is greater than 20%, or the spring-to-spring resistance does not read approximately twice the spring-to-ground reading.

Figure 4 – Igniter hinge and retainer clips



E. Servicing nozzle line assembly

Before proceeding, turn off power to the burner.

1. Disconnect the oil connector tube from the nozzle line.
2. Referring to Figure 4, loosen the two screws securing the igniter retaining clips and rotate both clips to release the igniter baseplate. Then tilt the igniter back on its hinge.
3. Remove the splined nut.
4. Remove the nozzle line assembly from the burner, being careful not to damage the electrodes or insulators while handling. To ease removal of long assemblies (over 9 inches), rotate the assembly 180° from the installed position after pulling partially out of the tube.
5. To replace the nozzle line assembly, reverse the above steps.

F. Check/adjust "Z" dimension

Refer to Figure 5. The critical "Z" dimension is the distance from the face of the nozzle to the flat face of the head. This distance for F heads is 1 1/4". The "Z" dimension is factory set for burners shipped with the air tube installed but should always be verified during service and installation. If the "Z" dimension is out of adjustment, perform the following steps.


Before proceeding, turn off power to the burner.

1. Disconnect the oil connector tube from the nozzle line.
2. Referring to Figure 3, loosen the splined nut from the nozzle line. Loosen the hex head screw securing the escutcheon plate to the burner housing.
3. A Beckett T650 gauge should be used to set the Z-dimension. Place the end of a ruler at the face of the nozzle end, using a straight edge across the hood, measure the distance to the face of the head.
4. Slide the nozzle line forward or back until this dimension for F heads is 1 1/4".
5. Tighten the hex head screw to secure the escutcheon plate to the burner chassis. Then tighten the splined nut and attach the oil connector tube.
6. Recheck the "Z" dimension periodically when servicing to ensure the escutcheon plate has not shifted. You will need to reset the "Z" dimension if you replace the air tube or nozzle line assembly.

NOTICE

The Beckett Z gauge (part number Z-2000) is available to permit checking the F head "Z" dimension without removing the burner.

Figure 5 – Z- Dimensions using gauge



4. Fuel Supply Maintenance

A. Connect fuel lines

For oil supply system specifications for tanks not mounted on machines, carefully follow the pump manufacturer's literature and the latest edition of NFPA 31. If this information is unavailable, use the following basic guidelines:

NOTICE

Pumps with automatic bypass do not require a bypass plug.

WARNING

The burner pump is shipped without the bypass plug installed. You must install this plug on two-pipe oil systems. If the unit is a one-pipe oil system DO NOT install the plug in the pump. Failure to comply could cause pump seal failure, oil leakage and the potential for a fire and injury hazard.

B. Fuel supply level with or above burner

The burner may be equipped with a single-stage pump. If a one pipe system is installed, insure that a bypass plug is not installed in the pump, then connect the fuel supply to the burner with a single supply line. Note that manual bleeding of the pump is required on initial start-up. When connecting a two-pipe fuel supply, install the pump bypass plug.

WARNING

The oil supply inlet pressure to the pump cannot exceed 3 psi. Install a pressure-limiting device in accordance with NFPA 31.

5. Burner Maintenance & Wiring

A. Burner Installed on Washer

Refer to appliance manufacturer's wiring diagram for electrical connections. Refer to Appendix A for burner maintenance procedures.

B. Burner Replacement

Burner wiring may vary, depending on the actual primary control and furnished options. Refer to Figure 6 for typical burner wiring, showing CAD cell primary controls. Note that the relay and control, shown in the wiring diagram are optional features.

C. Fuel supply below level of burner

When the fuel supply is located below the level of the burner, a two-pipe fuel supply system is not necessary, but depending on the fuel line diameter and horizontal and vertical length, the installation may also require a two-stage pump. Consult the pump manufacturer's literature for lift and vacuum capability.

D. Fuel line replacement (remote tank only)

When replacing fuel lines, continuous lengths of heavy wall copper tubing is recommended. To ensure a tight seal, always use flare fittings. Never use compression fittings.

Always install fittings in an accessible location. To avoid vibration noise, fuel lines should not run against the appliance or the ceiling joists.

WARNING

Never use Teflon tape on any fuel fitting. Tape fragments can lodge in fuel line components and the fuel pump, damaging the pump and preventing proper operation.

E. Fuel line valve and filter

Shutoff valves should be located in the oil supply line, never the return line.

All wiring must be in accordance with the latest revision of National Electric Code NFPA 70 and all local codes and regulations.


NOTICE

The wiring diagrams in this manual are for general reference only. Refer to the equipment manufacturer's literature or the diagrams supplied with the equipment. Failure to install correct wiring could result in severe personal injury, death or substantial property damage.

WARNING

Electrical shock hazard. Disconnect power before servicing.


Figure 6A – Recommended Field Wiring

**NOTES:**

1. All wires are to be 14 GA. Minimum (18 GA, for valve & igniter) to prevent voltage drop between battery and burner.
2. Motor runs continuously in normal configuration.
3. Optional motor configuration shown in dashed lines cycles motor with trigger. K1 relay to be S.P.S.T. N.O. contacts with 26 A minimum current rating, (100 amp in-rush) @ 12 volts DC.

540789


Figure 6B – Wiring with ICB

**NOTES:**

1. All wires are to be 14 GA. Minimum (18 GA, for valve & igniter) to prevent voltage drop between battery and burner.
2. Alternate wiring: white wire of ICB may be wired to red wire of ICB, and positive valve wire may be wired to flow or pressure switch.
3. Hard-wire burner ground to battery. DO NOT USE CHASSIS GROUND SYSTEM.

540790

Figure 6C – Wiring with 7434 Control



6. Drive component maintenance


A. Motor, blower wheel, and coupling replacement

The motor will require replacement if the proper voltage is measured at the motor input, and the motor will either not run, or the current draw with a free running pump exceeds 10% of the rated current.

To replace the burner motor, coupling and/or blower wheel perform the following steps.

1. Before servicing, turn off and/or disconnect all power to the burner.
2. Disconnect the burner motor wires.
3. Remove the bolts securing the motor to the burner housing.
4. Remove the motor, coupling, and blower wheel.
5. Loosen the set screw on the blower wheel to slide the existing wheel off the shaft.
6. Slide the new blower wheel onto the old shaft (after thoroughly cleaning housing) and/or slide the old blower wheel onto the new motor shaft.
7. Place a .030" ($\frac{1}{32}'' \pm \frac{1}{64}''$) feeler gauge between the blower wheel and the motor housing.
8. Slide the blower wheel toward the motor until it contacts the feeler gauge.
9. Rotate the blower wheel until the setscrew is centered on the flat of the motor shaft. Tighten the setscrew to secure the wheel.

Figure 7. – Blower Wheel



10. Slide the motor coupling on the motor shaft then install the motor on the burner housing. Insure that the motor coupling fits between the motor shaft and the pump shaft inside the housing. Tighten the motor retaining screws. Reconnect the wires.
11. Restore power, start the burner and perform the combustion test described previously in this manual.

Instruction Manual – Model ADC Oil Burner

B. Pump Maintenance

CAUTION

This Equipment must be installed, adjusted and started only by a qualified service technician. – an individual or agency, licensed and experienced with all codes and ordinances, who is responsible for the installation and adjustment of the equipment. The installation must comply with all local codes and ordinances and with the National Fire Protection Association Standard for Liquid Fuel Equipment, NFPA 31 (or CSA B139).

General pump information

Important information - Long or oversized inlet lines may require the pump to operate dry during initial bleeding period. In such cases, the priming may be assisted by injecting fuel oil in the pump gear set. Under lift conditions, lines and fittings must be air tight. To assure this, "Pipe Dope" may be applied to both the used and unused inlet and return fittings.

CAUTION

Do NOT use Teflon tape! Do NOT use compression fittings!

Mounting Position - Beckett CleanCut pump may be mounted in any position (except upside-down during single pipe installation).

Vacuum check - A Vacuum Gage may be installed in either of the 1/4" NPT inlet ports.

Pressure check- When a pressure check is made use the nozzle port. If the bleed port is used, the reading on the gauge should be approximately 5 psig higher than the pressure reading on the nozzle port.

Cutoff check - To check cutoff pressure dead head a pressure gage in the nozzle port. Run the burner for a short period of time. Shut the burner off. The pressure will drop and hold above zero.

CAUTION

Pressurized or gravity feed installations must not exceed 3 psi on inlet line or return line at the pump per NFPA 31. A pressure greater than 10 psi may cause damage to the shaft seal.

Mounting the pump

To install a CleanCut pump on a pre 2002 burner chassis with an existing shutter tab follow the instructions included with the pump.

C. Valve Coll and Stem Replacement


To determine if the valve coil requires replacement perform the following steps.

1. Remove the cord set from the valve.
2. Place the leads from an ohmmeter across the coil.

Beckett

3. A 12 volt coil should measure between 15 and 25 ohms.
4. If the meter indicates an open circuit, replace the coil.

Figure 8. – Pump and Valve assemblies



To check pump operation perform the following.

1. Check the operating pressure by removing the copper tubing from the nozzle line and installing a pressure gauge in the line. With the motor running and the coil energized, check the gauge. The pressure should read 100 psig unless otherwise stated.
2. To check the cutoff function, deadhead the pressure gauge onto the copper connector tube attached to the nozzle port. Run the burner for a short period of time. Shut the burner off; the pressure should drop and hold.

To replace the coil and/or valve stem assembly perform the following steps.

1. Before servicing, turn off and/or disconnect all power to the burner.
2. Use the shut-off valve between the fuel tank and the pump to block oil from the burner.
3. Remove the copper Tube Assembly when replacing the pump or when removing the coil and the tube blocks the coil.
4. Using a flat tip screwdriver, press the flat tip into the spring washer to prevent it from rotating.
5. Using a 10mm wrench or adjustable wrench, remove the nut and spring washer.
6. Remove the coil by lifting it straight up.
7. Remove the two base plate screws, then the base plate by lifting straight up.
8. Remove valve stem assembly by pulling straight up.
9. To install the new stem and coil assemblies, follow the above steps in reverse order, tightening each part as you go.
10. Restore power, start the burner and perform the combustion test described previously in this manual.

7. Start up burner & Set combustion

A. Basic burner operation

On the Beckett ADC Oil burner standard configuration, the motor and igniter operate continuously while the valve, that controls oil flow, is cycled by the switches on the power washer. The motor is used to drive the blower and pump. The rotational speed of the motor is determined by the voltage supplied and the load placed on the motor. Pump pressure and air settings are the main factors affecting the motor load. The igniter converts battery DC voltage into a high voltage spark to ignite the oil. The igniter is capable of running continuously as long as the blower wheel is circulating air across the igniter base. The pump and solenoid valve are used to control the flow of oil from the reservoir to the nozzle. The pump pressurizes the oil. When energized, the valve enables high pressure oil flow to the nozzle. An optional control circuit can also be supplied to reduce current draw on the charging system by turning the igniter off after a flame has been established. This option controls igniter operation based on a signal from a light sensing CAD cell. When light hits the cell the control will sense a decrease in resistance across the sensor. A few seconds delay will occur prior to the igniter switching off. As long as sufficient light is reaching the cell eye, the igniter will remain off. If light is removed from the sensor, the igniter will turn on until light is again sensed by the CAD cell.

Variations to the burner circuits may occur due to optional temperature, pressure, and vacuum switches that control burner operation. Note that when external switches are used to control the motor operation they must be sized correctly for the rated current or a relay should be installed to isolate the switches from the motor's full load current.

B. Combustion set-up

WARNING:

Do not attempt to start the burner if excess fuel or vapor has accumulated in the equipment. Starting the burner under these conditions could result in a puffback of hot combustion gases, high smoke levels, or hazardous operation.

Open all shutoff valves located in the oil supply line to the burner.

As soon as burner motor starts rotating bleed all the air from the pump. (Required with single-pipe systems)

To bleed the pump, attach a clear plastic hose over the vent fitting. Loosen the fitting and catch the oil in an empty container. Tighten the fitting when all air has been purged from the supply system. Note: If the burner stops after a flame is established, the unit probably requires additional bleeding. Continue to bleed the system until the pump is primed and a flame is established when the vent fitting is closed.

C. Set combustion with instruments

WARNING:


The combustion level should be adjusted using dedicated combustion test equipment. Failure to properly set the burner could result in inefficient operation, and/or conditions that could potentially cause severe personal injury, death or substantial property damage.

NOTICE

Combustion testing instruments can be purchased from most HVAC suppliers. If your usage does not warrant purchasing the equipment, contact a reputable HVAC contractor to perform a combustion test and adjustment.

1. Allow the burner to run for approximately 5 to 10 minutes.

Figure 9. – Air supply components



2. Follow these three steps to properly adjust the burner:
 - Step 1: Use a smoke tester to check for a clean flame. If necessary, adjust the air shutter and air band to obtain a trace to one smoke. See Figure 2.
 - Step 2: With the smoke level at a trace to one, measure the CO₂ (or O₂). This will be the reference point for further adjustments.
 - Step 3: Increase the air to reduce smoke levels to zero or a trace. Recheck the CO₂ (or O₂). It should be lower than the initial reading.
3. Once the combustion level is set, tighten the fasteners on the air band and air shutter.
4. Start and stop the burner several times to ensure satisfactory operation.
5. Test the equipment safety controls to verify that they function according to the manufacturer's specifications.

Appendix A. Maintain & Service Burner**A. Owner's Information****WARNING**

Have your equipment inspected at regular intervals by a qualified service agency to assure continued proper operation. The burner should be adjusted using dedicated combustion test equipment. Failure to properly set the burner could result in inefficient operation, and/or conditions that could potentially cause severe personal injury, death or substantial property damage.

The following could result in fire hazard, severe personal injury, death or substantial property damage. Read carefully.

- Never attempt to use gasoline in your burner.
- Never store gasoline or combustible materials near the burner.
- Never attempt to light the burner by throwing burning material into the fire chamber.
- Never attempt to use crankcase or waste oil or material other than the approved fuel oils in this burner.
- Never restrict the air inlet openings to the burner or the combustion air ventilation openings in the room.

B. Owner service and maintenance

Properly installed and maintained, your ADC burner will provide years of efficient, trouble-free operation. Please take care of your equipment by following the warnings provided and by doing the following (notify your qualified service agency if your burner is not operating properly):

WARNING

This equipment should be serviced only by a qualified service agency. The appropriate test instruments must be used. Failure to do so could result in burner or equipment failure, could potentially cause severe personal injury, death or substantial property damage.

C. Daily

Check the areas around your burner/equipment to make sure:

- air ventilation openings are clean and unobstructed
- nothing is blocking the burner inlet air openings
- no combustible materials are stored near the equipment
- there are no signs of oil or water leakage around the burner or equipment

D. Extended down time

If the equipment will be stored for an extended period of time, insure that the fuel tank is full and add a fuel stabilizer to the tank.

E. Regular Service/Maintenance

Have your burner, power washer, crack sealer, etc. serviced annually by your qualified service agency.

The following components/assemblies should be checked/adjusted/replaced on a regular basis. Refer to the Replacement Parts exploded view for part locations.

- Replace the oil supply line filter if applicable. The line filter cartridge must be replaced to avoid contamination of the pump and nozzle.
- Inspect the oil supply system. All fittings should be leak-tight. The supply lines should be free of water, sludge and other restrictions.
- Remove and clean the pump strainer.
- Replace the nozzle with one having the same specifications from the same manufacturer.
- Clean and inspect the electrodes for damage, replacing any that are cracked or chipped.
- Check electrode tip settings. Replace electrodes if tips are rounded.
- Inspect the igniter spring contacts. Clean or replace if corroded.
- Clean the cad cell, if applicable.
- Make sure Low Firing Rate Baffle is in place if required for the burner application. Omitting the baffle can result in unacceptable burner combustion.
- Inspect all gaskets including the igniter base plate gasket. Replace any that are damaged or missing.
- Clean the blower wheel, air inlet, air guide, retention head and static plate of any dirt, asphalt or other material.
- Check motor current. The amp draw should not exceed the nameplate rating by more than 10%.
- Check all wiring for loose connections or damaged insulation.
- Check the pump pressure and cutoff function.
- Check primary control safety lockout timing, if applicable. Refer to the information supplied by the control manufacturer for procedures.
- Check ignition system for proper operation.
- Inspect the exhaust system for soot accumulation or other restriction.
- Clean the equipment thoroughly according to the manufacturer's recommendations.
- Check the burner performance. Refer to Section 3.
- It is good practice to make a record of the service performed and the combustion test results.

Appendix B. Burner Troubleshooting

Oil burners that are designed for use in pressure washers are built to take temperature extremes vibration and rough handling. When performing the following troubleshooting steps, we assume that the oil burner motor and ignition transformer operate continuously and the oil solenoid valve, which controls oil flow, is cycled by the trigger on the wand. We also assume that there is power to the burner, and fuel in the tank.

In addition to normal mechanic's tools, it is recommended to have the following equipment on hand. An electrical meter capable of measuring volts, ohms, and amps, an ignition transformer tester, a smoke pump tester, combustion analyzer and a zero to 200 psi oil pressure gauge.

Troubleshooting Chart

Symptom	Possible cause	Additional info/Procedure
Oil not igniting	If the burner is not igniting, the burner motor, drive coupling, and oil pump are operating and oil is flowing to the nozzle through the solenoid valve, check the following possibilities. 1) Check the air shutter adjustment. If the air shutter is opened too far, the flow of air may prevent the igniter from reaching the oil spray. This may appear as a white vapor exhaust from the coil. 2) The ignition system may have failed to supply an adequate arc to ignite the oil. Check the battery and charging system to insure a continuous supply of 11 to 16 volts DC (15 amps). 3) Check the electrodes for wear and damage. Insure that the electrodes are adjusted properly.	1) Refer to Section 7, C. 2) Refer to Section 2. 3) Refer to Section 3, C.
No Flame	If there is no flame, the burner motor and ignition transformer operate continuously and the oil solenoid valve, which controls oil flow, is cycled by the trigger in the wand, check the following possibilities. 1) Check for a plugged oil nozzle. 2) If the coil on the solenoid valve is actuating, insure that the valve is opening. 3) Check for sufficient fuel pressure. Pressure is 100psiG unless otherwise noted. 4) Check the pump pressure. Check for air in fuel lines. 5) Check burner for broken motor coupling. If the coupling is broken check pump rotation prior to replacing the coupling. 6) Check for contaminated fuel and/or partially plugged fuel filter.	1) Refer to Section 3, A. 2) Refer to Section 6, C. 3) Refer to Section 6, B. 4) Refer to Section 6, B. 5) Refer to Section 6, A. 6) Refer to Section 4, E.
Motor not operating	If the blower motor is not operating, check the following possibilities. 1) Check voltage at the motor to insure that switches and relays, in line with the motor, are operating properly. 2) Check pump and motor shaft operation. They should work freely without binding. 3) Check the fuse and/or breaker on the motor.	1) Refer to Section 2. 2) Refer to Section 6, B. 3) Refer to Section 6.
No oil spray	If the blower motor is operating, there is fuel in the reservoir, but oil does not spray out the end of the nozzle, check the following possibilities. 1) Check for a broken or stripped coupling between the pump and the motor. 2) Check the pump output for oil. 3) Check operation of the oil valve. 4) Check for a plugged nozzle 5) Check for air in the oil line 6) Check for fuel contamination or plugged filter	1) Refer to Section 6, A. 2) Refer to Section 6, B. 3) Refer to Section 6, B. 4) Refer to Section 3, A.

Instruction Manual – Model ADC Oil Burner

Fluctuating or no pump pressure	If the pump pressure, as determined by a pressure gauge, is erratic or does not exist, check the following possibilities. 1) Check motor rotational speed. Low rpm's can cause erratic or no pump pressure. 2) Check for a broken or worn motor coupling 3) Check that the pump turns freely 4) Check for air leaks in the lines 5) Check for oil froth within the reservoir 6) Check voltage at the motor 7) Check for fuel contamination or partially plugged filter	1) Refer to Section 6, A. 2) Refer to Section 6, B. 3) Refer to Section 6, B. 4) Refer to voltage rating on Nameplate.
Slow motor rotation	If the blower motor is not operating at the rpm's listed on the nameplate, check the following. 1) Check the supply voltage to the motor. 2) Check for free operation of the motor shaft and pump assembly.	1) Refer to voltage rating on Nameplate. 2) Refer to Section 6, A & B.


Appendix C. Replacement PartsFor best performance specify genuine **Beckett** replacement parts

Illustration #	Description	Part#
1	DC Motor	21699U
2	Blower Wheel	2140401
3	Coupling	21405
4	Air Guide	31231U
5	Burner Housing - Black-Grey	587486U 5877
6	Air Band	5151501
7	Air Shutter 4 Slot	3709
	Air Shutter 6 Slot	3494
8	Cord set	21807
9	Pump (GearCut)	2184402U
10	Tube assembly	21877U

Illustration #	Description	Part#
11	12 volt Coil	21754U
12	Escutcheon plate spline nut	3666
13	Escutcheon plate	3463
14	Electrode kit	5700
15	Cad cell detector	74827006
16	Igniter gasket kit	51411
17	Igniter w/o ICB	51776U
	Igniter w/o ICB	51777U
18	Air tube assemblies	Specify
19	Flange mounting gasket	
20	Ignitor only	7435U
21	Ignitor Control Board	51663

Limited
WARRANTY
 For Residential, Commercial and Specialty Burners

The R. W. BECKETT CORPORATION ("Beckett") warrants to persons who purchase its Beckett burners from Beckett for resale or its incorporation into a product for resale ("Customer") that its equipment is free from defects in material and workmanship under normal use and service for 60 months from the date of manufacture for Residential Burners and 18 months from the date of manufacture for Commercial and Specialty Burners. Residential burner models include: AF, AFO, AFE, NX, SF, SR and SMC. Commercial burner models include: CF775, CF350, CF700, CF1400, CF2000A, CF2500A, CG15, CG25 and CG30. Specialty burner models include: ADC, ADCP, ARV, SDC and SM. The provisions of this warranty are extended to individual major burner components as follows:

- i) 60 months from date of manufacture for all Beckett-branded major components, except for 12 Vdc components.
- ii) 18 months from date of manufacture for all non-Beckett-branded major components and Beckett-branded 12 Vdc components.

Note: Normal service items found to be defective upon receipt by the customer are covered by this warranty.

THIS WARRANTY DOES NOT EXTEND TO EQUIPMENT SUBJECT TO MISUSE, NEGLECT, OR ACCIDENT. NOR DOES THIS WARRANTY APPLY UNLESS THE PRODUCT COVERED BY IT IS PROPERLY INSTALLED BY A QUALIFIED, COMPETENT TECHNICIAN, WHO IS LICENSED WHERE STATE AND LOCAL CODES REQUIRE, AND WHO IS EXPERIENCED IN MAKING SUCH INSTALLATIONS, IN ACCORDANCE WITH THE LATEST EDITION OF NFPA NO. 54 OF THE NATIONAL FIRE PROTECTION ASSOCIATION, THE LATEST EDITION OF THE NATIONAL FUEL GAS CODE (NFGA NO. 14) AND IN ACCORDANCE WITH ALL APPLICABLE LOCAL, STATE AND NATIONAL CODES HAVING JURISDICTIONAL AUTHORITY.

Equipment, which is defective in material or workmanship and within the warranty period, may be repaired for credit as follows:

Becket Burners, Becket-branded major components and non-Becket-branded major components that came as original equipment on a Becket burner or were sold as a replacement part by Becket should be returned, freight prepaid, to Becket's home office. Credit will be issued to the customer unless the repair expense is determined by Becket to be out of warranty or damaged by user, in which case the equipment will be scrapped.

Note: Becket is not responsible for any labor cost for removal and replacement of equipment.

THIS WARRANTY IS LIMITED TO THE PRECISE TERMS SET FORTH ABOVE, AND PROVIDES EXCLUSIVELY REMEDIES EXPRESSLY IN LIEU OF ALL OTHER REMEDIES, AND IN PARTICULAR THERE SHALL BE EXCLUDED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO INDIVIDUAL WILL RECEIVE ANY LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE OF ANY NATURE. Becket neither assumes nor authorizes any person to assume for Becket any other liability or obligation in connection with the sale of this equipment. Becket's liability and Customer's exclusive remedy being limited to credit as set forth above.

R.W. BECKETT CORPORATION

P.O. Box 1289 • Elyria, Ohio 44036

Form No. 6104BADC R005

R.W. BECKETT CORPORATION

U.S.A.: P.O. Box 1289 • Elyria, Ohio 44036

Canada: R.W. Beckett Canada, Ltd. • Unit #3, 430 Laird Road • Guelph, Ontario N1G 3X7

Form Number 6104BADC R005



6104BADC*



0 40058 00907 0